























## HVR Web Interface

Home Network Setup

The HVR Solid State Recorder utilizes proven alreraft The HVR Solid State Necorder utilizes grown alreaff technology to provide strange questive percenting 12 hours of rabat, sersor, and oatho that. The final hours of rabat, sersor, and oatho that. The final within the HVR that as fixed with a the HVR that as fixed with an Underwater Locatus Beacon (ULE) in ad in locating the recorder Locatus Beacon (ULE) in ad in locating the recorder in event of a castactaphic location. The HVR will be located in the victarity of the bidge on the external deck case of a sweet do say on maximum etc. probability of its action of a vessel do say on maximum etc. probability of its action of a vessel of says of the probability of the says of the strange of the

Flash Setup Sys Maintenance

survival and recovery following an incident

Sys Information Set Password

The HVR is designed to meet or exceed the following IEC test specifications:

Shack - 11 millisecond duration or 50g Penetration - 3m, 250 kg drop test

HVR Interface

- Fire 1100 C for 1 hour / 260 C for 10 hours
- Deep Sea Immersion 30 days at 6 000m of depth

F16.12

(	Login Screen		==
Home			
(Network Setup		Administrat	or Access
(Sys Maintenance)		Enter Password:	
(Sys Information)			Submit
(Set Password)			
HVR Interface	× 1		

F16, 13

(	Network Setup	<u> </u>	
Home	Parameter	Current Value	New Value
Network Setup	HVR IP Address	192.168,0,2	
Flash Setup	HVR Subnet Mask	255.253.25a.0	
	Default Gateway IP	192 158.0.1	
Sys Maintenance	Session Time-out (Seconds)	300 seconds	
Sys Information		t recommendation	
Set Password			Submit
HVR Interface			

F16,14

Update Devices							
Home	11VR Memory Partition Configuration						
Network Setup	Total Decores in Crash Module   96     Number of Hyrrs Zer Decice   16771716     Courterly Consequed Decores   0						
Flash Setup							
Sys Maintenance	Update Device Allocations and Stream Names						
Sys Information	Position	Devices	Drvices	Stream Name	Stram Name		
	0	16	[]	Strean_0			
( Set Password )	1	16		Stream_1			
(HVR Interface	2	16		Stream_2			
	3	16		Stream_3			
	4	16		Stream_1			
	5	16		Strenu5			
	в	0		Stream_6			
	7	0		Sucani_7			
	8	0		Stream_8			
	9	0		Stram_9	لحتتال		
					Suhmit Changes		

F16.15